## Battery Replacement Guide for AssetScan Models ASB, ASM, ASV



The power of analytics. Delivered.









## Battery Replacement Guide for AssetScan Models ASB, ASM, ASV



The power of analytics. Delivered.













Access the power of technology.



- 2 Lay new battery in case so bottom of battery is against left side of case.
  - Make sure terminals are towards back of case.



10

- Slide Velcro strap through metal buckle.
- Pull on edge and end of Velcro strap in order to feed across battery to position buckle at bottom of case.
  - Pull tight and fasten Velcro to itself around battery.
- **11** Close and latch lid.

## Please recycle old battery at a local recycling center.

## 223-0165-000 Rev. B 6/18

ATEK Access Technologies 10025 Valley View Road, Ste. 190 Eden Prairie, MN 55344 U.S.A.



www.atekaccess.com

©2018 ATEK Access Technologies, LLC. All Rights Reserved. AssetScan images and marketing materials are protected by various patents, copyrights and/or trademarks. ATEK assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of ATEK are granted by the Company in connection with the sale of TankScan products, expressly or by implication.